


Position	Part number	Name
4	927500004	Front handle
5	927500005	Exhaust pipe cover
6	927500006	Lower gearcase
10	927500010	Base
12	927500012	Left part of handle
13	927500013	O-ring 43,8x3,1
14	927500014	Rotation lever spring
15	927500015	Handle rotation control lever
16	927500016	Throttle trigger
17	927500017	Safety lever
18	927500018	Right part of handle
19	927500019	Handle grip
20	927500020	Engine stop switch
24	927500024	Safety lever spring
25	927500025	Throttle trigger spring
26	927500026	Position block
30	927500030	Throttle cable
32	927500032	Washer
33	927500033	Spring
35	927500035	Spring
36	927500036	Connecting rod
37	924002017	Bearing 61805-Z
38	927500038	Eccentric gear
39	927500039	Gearcase gasket
40	608-ZZ	Bearing 608-RS
41	927500041	Output shaft
42		Bearing 6001-RS
46	927500046	Upper gearcase
47	927500047	Grease fitting
48	927500048	Clutch drum
50	927500050	Exhaust pipe
52	927500052	Washer
55	924002020	Pin 6x35
56	927500056	Blade
57	927500057	Bushing
58	927500058	Lower guide bar
60	927500060	Upper guide bar
61	927500061	Upper plate
64	927500064	Bushing
65	927500065	Screw M5x40
66	927500066	Upper unsharpened blade
68	927500068	Front guard
71	927500071	Blade cover



Position	Part number	Name
1	927501001	Air filter screw
2	927501002	Air filter cover
3	927501003	Air filter
4	927501004	Air sponge filter
8	927501008	Choke flap board
10	927501010	Air filter base
11	927501011	Choke lever
12	927501012	Air filter gasket
13	927501013	Cable support
14	927501014	Carburetor
15	927501015	Carburetor gasket
20	927501020	Carburetor insulator
21	927501021	Insulator gasket
27	927501027	Ignition coil
28	927501028	Spark plug
33	927501033	Plastic muffler cover
37	927501037	Muffler cover
40	927501040	Exhaust pipe
41	927501041	Exhaust pipe gasket
42	927501042	Muffler
43	927501043	Muffler gasket
45	927501045	Cylinder
46	927501046	Cylinder gasket
47	927501047	Piston ring
48	927501048	Piston
49	927501049	Piston pin clip
50	927501050	Crankshaft
51	927501051	Bearing 6000
53	927501053	Crankcase gasket
54	927501054	Lower crankcase
55	927501055	Oil seal 10x20x5
60	927501060	Clutch assembly
61	71-P-01	Primer
62	927501062	Fuel tube 75mm
63	927501063	Fuel tube 100mm
64	927501064	Fuel tube grommet
65	927501065	Fuel tube 230mm
67	927501067	Fuel filter
69	927501069	Fuel tank
70	927501070	Rubber shock absorber
71	927501071	Fuel tank cap
79	927501079	Engine top cover
90	927501090	Starter assembly
92	927501092	Flywheel
94	927501094	Upper crankcase
95	927501095	Woodruff key
96	927501096	Needle bearing 8x11x10
97	927501097	Piston pin